



godwin 



a xylem brand

OPERATOR HANDBOOK

Heidra Pumps



HS80
 HS100
 HS100NC
 HS100-SG
 HS103
 HS150
 HS150NC
 HS150-SG
 HS150V
 HS150V-SG
 HS150HH
 HS200
 HS200-SG
 HS250
 HS300



READ BEFORE INSTALLING OR OPERATING THIS EQUIPMENT

Xylem Dewatering Solutions UK Ltd
 Quenington
 Cirencester
 Gloucestershire
 GL7 5BX,
 England

Tel: *44 (0)1285 750271
 Fax: *44 (0)1285 750352
 E-mail: sales@godwinpumps.co.uk
 Website: www.godwinpumps.co.uk

Pump Serial Number

Xylem Dewatering Solutions
 One Floodgate Road
 Bridgeport
 New Jersey 08014
 U.S.A.

Tel: 856 467 3636
 Fax: 856 467 4841
 E-mail: sales@godwinpumps.com
 Website: www.godwinpumps.com

Book No	95-0014-0000/A
Issue	6
Date	September 2012

CONTENTS

1 INTRODUCTION	3
2 HOW TO USE THIS HANDBOOK.....	3
3 SAFETY PRECAUTIONS.....	4
4 IDENTIFICATION	4
5 INSTALLATION.....	5
5.1 General Notes.....	5
5.2 Hydraulic motor.....	5
5.2.1 Determining motor inlet and outlet ports	5
5.2.2 Front seal removal	6
5.3 Hoses.....	7
6 OPERATION.....	7
6.1 Starting	7
6.2 Draining	7
6.3 Storage Procedure.....	7
7 MAINTENANCE	8
7.1 HS80 pumps	8
7.1.1 Dismantling	8
7.1.2 Reassembly	9
7.2 HS100, HS100-SG, HS103, HS150, HS150-SG, HS150V & HS150V-SG pumps	10
7.2.1 Dismantling	10
7.2.2 Reassembly	12
7.3 HS150HH, HS200-SG, HS200 & HS250 pumps.....	13
7.3.1 Dismantling	13
7.3.2 Reassembly	14
7.4 HS300 pumps	16
7.4.1 Dismantling	16
7.4.2 Reassembly	18
7.5 HS100NC & HS150NC Pumps	19
7.5.1 Dismantling	19
7.5.2 Reassembly	21
7.5.2.1 Guide Pin Fitting	21
7.5.2.2 Impeller Fitting	23
7.5.2.3 Adjusting Impeller Front Clearance.....	24
8 WARRANTY	25
9 FAULT FINDING	25
10 TECHNICAL DATA	26
10.1 HS80, HS100, HS100-SG, HS103, HS150, HS150V & HS150V-SG Pumps	26
10.2 HS150HH, HS200, HS200-SG, HS250 & HS300 Pumps	27
10.3 HS100NC & HS150NC Pumps	28
10.4 Fastener Torques.....	29

1 INTRODUCTION

The purpose of this Installation, Operating and Maintenance Handbook is to provide the owner or user of the equipment with sufficient information to carry out those tasks on the Heidra hydraulically driven range of vertical suction Submersible Pumps.

Pump models covered: -

HS80	HS103	HS150V-SG	HS250
HS100	HS150	HS150HH	HS300
HS100NC	HS150NC	HS200	
HS100-SG	HS150V	HS200-SG	

Because this handbook covers so many variants the user must ensure that they are reading the correct diagrams and instructions for the unit they are working on.

Installation and maintenance is designed to be carried out using simple hand and service tools. A range of special tools designed to ease dismantling and reassembly is available from Xylem Dewatering Solutions. When the user has insufficient tools, experience or ability, this work should not be attempted. Under no circumstances should makeshift tools or equipment be used, as this may adversely affect safe working practices and pump operation.

Ensure that suitably qualified personnel carry out the installation. The variety of conditions and environments in which this equipment can be used means that the operator and those responsible must satisfy themselves as to the safety and acceptability of each application and operating condition of this equipment. Under no circumstances will Xylem Dewatering Solutions be responsible or liable for indirect or consequential damages arising from the use or application of this equipment.

The pump may be supplied with or without a hydraulic motor fitted. This handbook covers the pump end only. For packaged pump sets, information on equipment other than the pump end is contained in separate documentation.

Parts that have not been approved by Xylem Dewatering Solutions cannot be relied upon for correct material, dimensions or finish. Xylem Dewatering Solutions cannot therefore be held responsible for any damage arising from the use of such parts. This and failure to observe any instruction or procedure in this handbook will invalidate the warranty.

The information contained in this handbook was correct at the time of publication. It is subject to amendment at any time. Should any doubt exist about the veracity of the information, contact Xylem Dewatering Solutions for clarification before proceeding.

Associated Publications: - 95-0014-0000/B Operator handbook – Heidra Power Packs.

2 HOW TO USE THIS HANDBOOK

Read this section before installing, operating or carrying out any maintenance on the unit.

When the pump is being installed operated or maintained there are a number of practices that may lead to personal injury or product damage. Your attention is drawn to the following symbols used throughout this handbook.



CAUTION. *This caution symbol draws attention to special instructions or procedures which, if not correctly followed, may result in damage to, or destruction of equipment.*



WARNING. *This warning symbol draws attention to special instructions or procedures which, if not strictly observed, may result in personal injury.*



WARNING. A WARNING SYMBOL WITH THIS TYPE OF TEXT DRAWS ATTENTION TO SPECIAL INSTRUCTIONS OR PROCEDURES WHICH, IF NOT STRICTLY OBSERVED MAY RESULT IN SEVERE PERSONAL INJURY, OR LOSS OF LIFE.

NOTE: -

A note is used to draw your attention to additional important information.

3 SAFETY PRECAUTIONS



WARNING. ALL ITEMS IN THIS SECTION, IF NOT STRICTLY OBSERVED, COULD RESULT IN SEVERE PERSONAL INJURY OR LOSS OF LIFE.

Only use lifting equipment of suitable capacity for the size and weight of the equipment being lifted. The pump units are designed for lifting by wire rope in use or slings around the workshop.

The equipment must always be lifted using safe working practices and in accordance with any local and national guidelines or statutes. If in doubt, consult Xylem Dewatering Solutions or a local lifting expert.

Whilst lifting the unit keep personnel well away and **never** allow people underneath.

Personnel working on the pump must always wear clean, correctly fitting clothing and safety footwear. Clothing impregnated with oil or fuel can constitute a health hazard through prolonged contact with the skin and may also constitute a fire hazard.

Check the type of liquid the pump has been used for before working on them. Residues could be hazardous to your health. If in doubt, flush thoroughly with clean water before commencing work.

Rotating equipment presents a hazard in itself. Alert surrounding personnel before starting and post notifications whilst in operation.

Moving parts are guarded to protect you. Guards removed for maintenance must be replaced before starting the pump.

Never insert anything into the pump body whilst the pump is running and the delivery hoses are disconnected.

Where connections are flanged, use all flange bolt holes and ensure the correct bolt size and quality is utilised when connecting suction and delivery hoses.

Where connections are threaded, ensure the threads are sound before use and protected from damage if left unconnected during storage or transportation.

Although the pump can handle solids up to the size indicated in the Technical Data section of this manual, larger or irregular solids may cause blockage with consequent damage to pump components.

Always allow adequate ventilation for the pump driver. Diesel engines require air for both combustion and cooling. Electric motors require air for cooling purposes. This air must never be allowed to recirculate.

Be aware of burn and fire risks from items such as diesel engine exhaust pipes and silencers. Never place flammable items around the unit.

Diesel engines exhaust and some of its constituents are known in the State of California to cause cancer, birth defects and other reproductive harm.

Liquid pressure may still be present even after shutdown of the pump. Particular attention should be paid to delivery lines that are long, or rise through any height, as these can contain large volumes of liquid. These lines must be isolated and drained down before commencing work. Sudden release of this liquid can cause serious injury to an operator either directly or indirectly through the rotational motion it can induce.

Never run the pump above its maximum speed.

Wear protective gloves when handling the equipment. There may be sharp metal edges.

4 IDENTIFICATION

Every pump unit has a nameplate similar to one of those shown below. This nameplate lists the serial number and type of the pump. **These numbers must be quoted in any enquiry for spares or service.**



5 INSTALLATION

5.1 General Notes

Xylem Dewatering Solutions may refute warranty liability if the installation does not meet the requirements of the pump. Consult Xylem Dewatering Solutions should any doubt exist over the suitability of an installation.

Only suitably qualified personnel (both mechanical and electrical) should carry out the installation. All local and national regulations in force must be observed.

The delivery pipe work should be kept as short as possible with a minimum number of large radii bends to minimise pipe friction losses. Fitting larger diameter pipe work than the pump outlet will maximise flow rates. Size increases in the horizontal plane should be achieved using eccentric reducers to minimise the risks of air locks.

Lay out above ground piping runs before connecting to the pump to ensure that tight bends and other flow restrictions are not included.

5.2 Hydraulic motor



CAUTION. Hydraulic motors on submersible pumps can suffer serious damage, including catastrophic failure, if they are operated in the wrong rotation.

This occurs when either the hydraulic pipe connections are made incorrectly; i.e. inlet line to the outlet side of the motor and vice versa or, a wrong rotation motor is fitted on replacement. Failures result in unnecessary down time and possible pollution from escaped hydraulic fluid. Correctly specifying a replacement motor and identifying the inlet and outlet motor ports on new or existing motors **before** connection and start up is critical.




Figure 1 Hydraulic system schematic

A Xylem Dewatering Solutions supplied system is fitted with male and female quick release couplings at all terminal points to prevent incorrect connection. A typical system illustrating this is shown in Figure 1.

5.2.1 Determining motor inlet and outlet ports

Many older motors have their bolted on connecting ports stamped with 'IN' or 'HIGH PRESSURE'. These stampings should be treated with a degree of caution as the ports could have previously been removed from the motor and replaced incorrectly. Later motors will have their rotation and 'IN' stamped on the body (see Figure 3). These may be taken as much more reliable, but even so caution must be exercised and the user must be satisfied that they are correct before proceeding.

The Xylem Dewatering Solutions serial number of the pump is vitally important in any request for spares. It will be found on a serial plate located on the main body of the pump. If the serial number cannot be found then the following procedure should be employed to determine the requirement.

It is important to understand that when specifying any directional rotation it **must** be qualified by stating the direction in which that rotation is viewed. This is illustrated in Figure 2 where, when viewed from above the submersible pump, the direction of rotation is clockwise, but the Xylem Dewatering Solutions method of specification is the direction of rotation looking from the underside (i.e. the inlet side) of the pump and is anti-clockwise. Figure 2 shows a Heidra 10022 submersible pump but the principles are equally applicable to any submersible pump.

1. Identify the submersible pump rotation – clockwise or anti-clockwise? (Refer to Figure 2).
2. The hydraulic motor rotation notation is the same as the pump; i.e. an anti-clockwise pump requires an anti-clockwise motor and vice versa.

- The output shaft from the motor is offset one way from the port centres in the body (see Figure 3). Ensure the motor is in the correct orientation to Figure 3 and identify the motor ports accordingly. Mark appropriately. Note that the hydraulic fluid passes around the outside of the gear wheels and not through the middle.
- Connect the high pressure feed to the 'IN' inlet port and the low pressure return to the outlet port.




Figure 2 Pump rotation




Figure 3 Hydraulic motor ports

5.2.2 Front seal removal

The bearings (and mechanical seal for HS80 units) of HS80, HS100, HS150, HS100-SG, HS150V, HS150V-SG, HS100NC and HS150NC pumps are designed to be lubricated and cooled by the hydraulic motor system oil. The oil is bled from the motor by removing the seal from the front cover. A typical motor front cover arrangement is shown in Figure 4. Removing the circlip allows the seal and O-ring to be withdrawn. On some pumps the seal is fitted from the inside of the front cover. In these cases the front cover will need to be removed prior to removing the seal. Note that this oil is returned to the hydraulic reservoir by a separate leakage line (see Figure 1).

On all other pumps the bearings and mechanical seal are enclosed in their own separately sealed housings and the motor seal must not be removed.




Figure 4 Typical motor front seal arrangement

5.3 Hoses

Maximum recommended hose lengths are: -

Pump	Flow Rate GPM(Imperial)/ litres per min	Hose length Metres/feet
HS80	2.6 / 12	35 / 115
	2.4 / 11	45 / 148
	2.2 / 10	50 / 164
	2.0 / 9.2	65 / 213
	The lengths are for ½" nominal bore hose with SAE 10 oil at 15°C. They may be increased by 50% if ¾" nominal bore hoses are used.	
HS100	9.6 / 36.4	15 / 49.2
	9.0 / 34.0	20 / 65.5
	8.5 / 32.0	30 / 98.5
	8.1 / 29.5	35 / 115
	6.8 / 25.5	40 / 131
	The lengths are for 5/8" nominal bore hose with SAE 10 oil at 15°C. They may be increased by 50% if ¾" nominal bore hoses are used.	
HS150	14.7 / 55.8	20 / 65.5 ⁽³⁾
	14.5 / 55.0	30 / 98.5 ⁽³⁾
	13.7 / 52.0	35 / 115 ⁽³⁾
	13.0 / 49.0	40 / 131 ⁽³⁾
	The lengths are for 3/4" nominal bore hose with SAE 10 oil at 15°C. They may be increased by 50% if 1" nominal bore hoses are used.	

Long hose lengths result in high back pressure in the return line

Table 1 Recommended hose length table

6 OPERATION

6.1 Starting

1. Before starting a system, the three-way valve (see Figure 1) is turned to direct the flow back into the reservoir.
2. Start the prime mover. This immediately starts the hydraulic pump. The flow should be allowed to continue back into the reservoir for a few minutes to allow the system to warm and enables visual checking for leaks or faults.
3. Operate the three-way valve to direct the flow to the hydraulic motor and product pump.
4. Vary the speed of the prime mover to regulate the product pump.



CAUTION. The three way valve should never be used to control the speed of the hydraulic motor and product pump. This will lead to overheating of the hydraulic fluid and consequential failure.

6.2 Draining

A pump situated in a position where it could be exposed to frost must be drained when that possibility exists unless steps have been taken to alleviate the condition.



CAUTION. Failure to drain the pump and non-return valve in these conditions could result in the pumped product residue freezing and cracking the casing.

It should also be drained if it is to be stopped for an extended period.

6.3 Storage Procedure

Disconnect the pump from the pipelines.

Allow air to circulate and try to ensure that the body is completely dry internally.

A proprietary flushing/protective fluid may be used if required. Ensure that this is compatible with any pump residue before using it.

Place the pump to a cool dry storage area.

7 MAINTENANCE

In this section it is assumed that the pump: -

- has been removed from its operating position
- has been drained of pumped product
- has been drained of hydraulic oil
- all hoses have been disconnected

7.1 HS80 pumps

7.1.1 Dismantling

1. Undo set screws (75) holding lifting bracket (25) to both the pump body (1) and outlet pipe (2). Remove lifting bracket.
2. Undo set screws (75) holding the strainer (24) to the pump body (1). Remove strainer.
3. Release the screws (72) holding the bearing bracket, wear plate and impeller assembly to the pump body (1). (NOTE. These are the screws on the larger PCD. The screws on the smaller PCD retain the wear plate to the bearing bracket).
4. Extract the bearing bracket assembly from the pump body (1). The extension pipe (2) and front wear plate (6) can be removed from the pump body (1) if required by removing the respective screws (71) or (79).
5. Place a bar through the vanes of the impeller (3) to lock it in position and prevent rotation. Unscrew (RH thread) and remove the impeller retaining screw (68) and washer (19). Note that the screw has a nylon plug through it that provides a self-locking function. The screw will therefore remain stiff to turn until this nylon plug is clear of the shaft.
6. Remove the impeller (3) and the wearing sleeve (4). Remove the impeller shims (if any were fitted) noting the number and thickness for comparison on rebuild. Remove the key (36).
7. Release the screws (72) holding the rear wear plate (5) to the bearing bracket assembly. Remove the wear plate to expose the mechanical seal housing (8).
8. Extract the mechanical seal housing (8) complete with O-ring (46) from the bearing bracket (12). The stationary seat of the mechanical seal will probably stay in the seal housing and can be removed by pressing out.
9. Carefully extract the mechanical seal (52) from the bearing bracket.
10. Release the screws (74) holding the hydraulic motor (55) to the bearing cover (11) and remove the motor.
11. Undo the screws (67) and remove the bearing cover (11) from the bearing bracket.
12. Press the shaft assembly out of the bearing bracket from the pump end.
13. Flatten the tags on the locking washer (42), prevent the shaft from rotating, and unscrew the bearing locknut (41).
14. Pull the ball bearing (39) off the shaft and remove the bearing outer (17) and inner (16) spacers.
15. Pull the roller bearing inner race (40) off the shaft.

Dismantling is now complete. Inspect all parts for damage or wear.




Figure 5 Typical HS80 pump

7.1.2 Reassembly

New seals and O-rings must be fitted when reassembling. It is also prudent to fit a new impeller retaining screw.

1. Heat both bearings (39 & 40) with a temperature controlled bearing heater until they are a consistent 110°C. Do not overheat or allow the bearings to remain at this temperature for longer than their fitting time.



CAUTION. *Bearing races must be pressed into position and not hammered either directly or by drift. Direct hammering will damage the bearing or rollers. Drift hammering will introduce swarf into the assembly. Either will result in early bearing failure.*

2. Once up to temperature, slide the roller bearing inner race (40) up hard against the shaft shoulder, fit the bearing inner (16) and outer (17) spacers and slide the ball bearing (39) up hard onto the spacers. Hold them in position for a minimum of 30 seconds. The locknut (41) fitted without the tab washer is suitable for this purpose. This allows the races to grip the shaft and prevent them from creeping away from the shoulder during cooling. Let the assembly cool completely.
3. Once cool, remove the lock nut (41), fit the locking washer (42) and refit the lock nut. Knock up at least two tags on the locking washer to secure.
4. Press the shaft assembly into the bearing bracket (12) from the motor end until the back of the ball bearing race is 6-7 mm below the surface. Use the bearing cover (11) without an O-ring (46) to press the assembly to its final position.
5. Remove the bearing cover (11), fit an O-ring (46), refit the cover and secure with screws (67).
6. Fit the hydraulic motor (55) to the bearing cover (11) and secure with screws (74). Note that the oil seal in the front of the motor must be removed beforehand (see section 5.2.2 for details).



CAUTION. *Failure to remove the hydraulic motor oil seal will block the oil feed to both the bearings and mechanical seal. Immediate failure of the seal and damage to the bearings will result.*

7. Clean the shaft thoroughly and lubricate with clean water or a diluted soft soap solution. **Do not use** heavy grease, silicone or PTFE based lubricants, as these would prevent the seal from gripping the shaft.



CAUTION. *Mechanical Seals are precision engineered devices. Extreme care must be taken to ensure that no damage occurs to the lapped faces. These faces must be kept absolutely clean throughout the entire installation. Do not touch them or allow any contaminant to come into contact with them. Soiled faces will have to be cleaned with appropriate degreasing cleaner and soft tissue. Failure to observe these precautions will lead to premature seal failure.*

8. Carefully slide the rotating parts of the mechanical seal (52) over the shaft until they abut the shaft shoulder.
9. Press the stationary seat of the mechanical seal (52) into the seal housing (8). Fit an O-ring (46) to the outside diameter and carefully press the assembly into the bearing bracket from the pump end.
10. Fit the rear wear plate (5) to the bearing bracket assembly using screws (72).
11. Fit the key (36), wearing sleeve (4) and impeller (3) to the shaft. Secure with the impeller retaining screw (68) and washer (19).
12. Measure the clearance between rear of impeller and rear wear plate. Remove the impeller and add shims as necessary to obtain the clearance given in the Technical Data section.
13. Refit the impeller, lock the assembly with a bar through the vanes of the impeller and torque the retaining screw to the value given in the Technical Data section.
14. Fit the front wear plate (6) to the pump body (1) using screws (79), spring (97) and plain (89) washers.
15. Fit the pump body (1) to the bearing bracket, wear plate and impeller assembly with screws (75), spring (94) and plain (87) washers. Measure the clearance between the front of the impeller and front wear plate and check that it corresponds to the value given in the Technical Data section. If it is not correct then the build is incorrect and the cause must be investigated before proceeding further.
16. Place a gasket (30) on the pump body (1), fit the extension pipe (2) and attach with screws (71) and washers (87).
17. Attach the strainer (24) to the pump body with screws (75), spring (94) and plain (87) washers.
18. Attach the lifting bracket (25) to both the pump body (1) and outlet pipe (2) using set screws (75), spring (94) and plain (87) washers.

Assembly is now complete, but before attaching the hydraulic lines, the unit must be filled with hydraulic oil to prevent dry running on start up. Ensure the unit is completely filled with no air locks before proceeding.

7.2 HS100, HS100-SG, HS103, HS150, HS150-SG, HS150V & HS150V-SG pumps

NOTE! The HS100NC & HS150NC pumps differ only in volute, impeller and associated parts. Therefore these dismantling and reassembly instructions can be followed in principle, but refer to section 7.5 for detail differences.

Note that dismantling and reassembly procedures refer to the item numbers in the illustrations and are correct for a directly corresponding build. However because of the number of possible build configurations some interpretation of the diagrams will be necessary for other pump variants. Some additional illustrations have been included to aid in this purpose.

7.2.1 Dismantling

Horizontal and vertical discharges pumps are available. Only one representative type of each pump has been illustrated for clarity.

1. If not previously done remove the stud adaptor (87) and associated fittings and drain the bearing bracket of hydraulic oil.
2. Remove plug (83) and drain the seal housing of oil.
3. HS100 pumps: -Undo set screws (56) holding lifting bracket (17) to the pump body (1).
HS150 pumps: - Undo nuts (64) from bolts (55) holding lifting bracket (17) to the extension pipe (6) and screws (59) holding lifting bracket to the pump body (1).
Remove lifting bracket.
4. Undo set screws (HS100 – 57; HS150 – 60) holding the strainer (16) to the pump body (1). Remove strainer.
5. Release the screws (HS100 – 55; HS150 - 58) holding the bearing bracket, wear plate and impeller assembly to the pump body (1). (NOTE. These are the screws on the larger PCD. The screws on the smaller PCD retain the wear plate to the bearing bracket).
6. Extract the bearing bracket assembly from the pump body (1). The front wear plate (5) can be removed from the pump body if required by removing the screws (HS100 – 58; HS150 - 59).
7. Place a bar through the vanes of the impeller (3) to lock it in position and prevent rotation. Unscrew (RH thread) and remove the impeller retaining nut (63) and washer (14). Note that the nut has a nylon insert that provides a self-locking function. The nut will therefore remain stiff to turn until this nylon insert is clear of the shaft.
8. Pull the impeller (3) off the shaft (13) and remove the key (9). Two off M10 tapped jacking screw holes are provided in the boss of the impeller if required to aid in its removal.
9. Release the screws (HS100 – 55; HS150 - 58) holding the rear wear plate (4) to the bearing bracket assembly. Remove the wear plate to expose the mechanical seals (40 & 39). The wear plate contains a seal seat (20) that is removed by releasing the circlip (43).
10. Slide the mechanical seals (40 & 39) off the shaft (13) and extract the seal seat from the bearing bracket (10).




Figure 7 Typical HS100 pump




Figure 6 Typical 15022 pump

11. Release the nuts (65) holding the hydraulic motor (76) to the bearing cover (11) and remove the motor.
12. HS100 only. Undo the screws (60) and remove the bearing cover (11) from the bearing bracket.
HS150 only. Remove bearing cover (11) from bearing bracket.
13. Press the shaft assembly out of the bearing bracket from the pump end.
14. Remove the internal plugs (84) from the pump end of the bearing bracket and using a pair of rods, press the roller bearing outer race out.
15. Flatten the tags on the locking washer (50), prevent the shaft from rotating, and unscrew the bearing locknut (49).
16. Pull the ball bearing (48) off the shaft and remove the bearing outer and inner (12) spacers.
17. Pull the roller bearing inner race (47) off the shaft.

Dismantling is now complete. Inspect all parts for damage or wear.




Figure 8 *Typical HS150V pump*




Figure 9 *Typical HS150V-SG*

7.2.2 Reassembly

New seals and O-rings must be fitted when reassembling. It is also prudent to fit a new impeller retaining nut.

1. Heat both bearings (47 & 48) with a temperature controlled bearing heater until they are a consistent 110°C. Do not overheat or allow the bearings to remain at this temperature for longer than their fitting time.



CAUTION. *Bearing races must be pressed into position and not hammered either directly or by drift. Direct hammering will damage the bearing or rollers. Drift hammering will introduce swarf into the assembly. Either will result in early bearing failure*

2. When to temperature, slide the roller bearing inner race (47) up hard against the shaft shoulder, fit the bearing inner and outer (12) spacers and slide the ball bearing (48) up hard onto the spacers. Hold them in position for a minimum of 30 seconds. Use the locknut (49) fitted without the tab washer for this purpose. This allows the races to grip the shaft and prevent them from creeping away from the shoulder during cooling. Let the assembly cool completely.
3. Once cool, remove the lock nut (49), fit the locking washer (50) and refit the lock nut. Knock up at least two tags on the locking washer to secure.
4. Press the roller bearing inner race down to the bottom of the bearing bracket (10) bore. Fit plugs (84) to the internal channels at the pump end of the bearing bracket.
5. Press the shaft assembly into the bearing bracket from the motor end until it is clamped hard together.
6. Fit an O-ring (36) to the bearing cover (11) and for 10022 pumps attach the cover to the bearing bracket with screws (60). On HS150 pumps place the cover in position.
7. Fit the hydraulic motor (76) and O-ring (34) to the bearing cover (11) and secure with half nuts (65) for HS100 pumps or full nuts (65) for HS150 pumps and spring washers (68). Check to see that the oil seal in the front of the motor has been removed (see section 5.2 details).



CAUTION. *Failure to remove the hydraulic motor oil seal will block the oil feed to the bearings. Damage to the bearings will result.*

8. Clean the shaft thoroughly and lubricate with clean water or a diluted soft soap solution. **Do not use** heavy grease, silicone or PTFE based lubricants, as these would prevent the seal from gripping the shaft.



CAUTION. *Mechanical Seals are precision engineered devices. Extreme care must be taken to ensure that no damage occurs to the lapped faces. These faces must be kept absolutely clean throughout the entire installation. Do not touch them or allow any contaminant to come into contact with them. Soiled faces will have to be cleaned with appropriate degreasing cleaner and soft tissue. Failure to observe these precautions will lead to premature seal failure.*

9. Carefully slide the rotating parts of the mechanical seals (39 & 40) over the shaft until they abut the seal seat.
10. Place an O-ring (35) in the groove in the back of the rear wear plate (4), place the seal seat (20) in position and secure with circlip (43).
11. Fit the rear wear plate (4) to the bearing bracket assembly using screws (HS100 – 55; HS150 – 58) and spring washers (68) having first fitted an O-ring (37) to the bearing bracket.
12. Fit the key (9) and impeller (3) to the shaft. Secure with the impeller retaining nut (63) and washer (14).
13. Measure the clearance between rear of impeller and rear wear plate. Remove the impeller and add shims (HS100 – 95; HS150 – 95, 96 & 97) as necessary to obtain the clearance given in the Technical Data section.
14. Refit the impeller, lock the assembly with a bar through the vanes of the impeller and torque the retaining screw to the value given in the Technical Data section.
15. Fit the front wear plate (5) to the pump body (1) using screws (HS100 – 58; HS150 - 59) and spring washers (HS100 – 69; HS150 - 68).
16. Fit the pump body (1) to the bearing bracket, wear plate and impeller assembly with screws (HS100 – 55; HS150 - 58) and spring washers (68). Measure the clearance between the front of the impeller and front wear plate. Remove the pump body from the assembly, detach the wear plate from the pump body and fit shims (HS100 - 97, 98 & 99; HS150 - 94) to obtain the clearance given in the Technical Data section. Reassemble and recheck.
17. Attach the strainer (16) to the pump body with screws (HS100 - 57; HS150 - 60) and spring washers (68).
18. HS100 pumps: -Attach the lifting bracket (17) to the pump body using set screws (56) and spring washers (68).
HS150 pumps: - Attach the lifting bracket (17) to the pump body with screws (59), plain (71) and spring (68) and with nuts (64), bolts (55) and washers (71) to the extension pipe (6).
19. Fill the seal chamber with oil (see Technical Data section) ensuring that no air pockets remain and plug off with plug (83).

Assembly is now complete, but before attaching the hydraulic lines, the unit must be partially filled with hydraulic oil to prevent dry running on start up.

7.3 HS150HH, HS200-SG, HS200 & HS250 pumps

Note that dismantling and reassembly procedures refer to the item numbers in the illustration and are correct for a directly corresponding build. However because of the number of possible build configurations some interpretation of the diagram will be necessary for other pump variants. Some additional illustrations have been included to aid in this purpose.

7.3.1 Dismantling

1. If not previously done remove the plugs (45) from the bearing bracket (75) and drain the oil. Remove the plug (44) from the adaptor (8) and drain any leakage.
2. Remove the plug (45) from the adaptor and drain the seal housing of oil.
3. Undo set screws (56) holding the strainer (9) to the pump body (1). Remove strainer.
4. Release the nuts (70) holding the bearing bracket, adaptor, wear plate and impeller assembly to the pump body (1). (NOTE. These are the nuts on the larger PCD. The screws on the smaller PCD retain the wear plate to the bearing bracket).
5. Extract the bearing bracket assembly from the pump body (1). The front cover (2) and wear plate (5) may be removed from the body by releasing the nuts (70). The front wear plate can be removed from the front cover by removing the screws (57).
6. Place a bar through the vanes of the impeller (3) to lock it in position and prevent rotation. Unscrew (RH thread) and remove the impeller retaining nut (47) and washer (48). Note that the nut has a nylon insert that provides a self-locking function. The nut will therefore remain stiff to turn until this nylon insert is clear of the shaft.
7. Pull the impeller (3) off the shaft (80) and remove the key (49). Four off M8 tapped jacking screw holes are provided in the boss of the impeller if required to aid in its removal. Shims (15, 16, 17 & 18) may be found on the shaft behind the impeller. These have been used to achieve the required rear clearance. Keep a check on quantity and thickness for comparison purposes when rebuilding.
8. Release the nuts (10) holding the rear wear plate (6) to the bearing bracket assembly. Remove the wear plate.
9. Undo and remove the socket head cap screws (60) holding the inner wear plate and seal carrier (4) to the adaptor (8). Remove this inner wear plate with care as it carries the seal seat (27). Once removed, the seal seat can be removed from the wear plate by undoing the screws (59) to release the seal clamping plate (7).
10. The mechanical seals (29) are now exposed and can be released by undoing their clamping screws. Ensure that the screws are fully retracted before moving the seals to ensure that they do not mark the shaft during removal. Slide the mechanical seals (2 off 29) off the shaft (80) and extract the seal seat from the adaptor (8).




Figure 10 Typical HS200 pump

11. Release the nuts (69) from bolts (54) and remove the lifting bracket (11) and adaptor (8) from the bearing bracket assembly.
 12. Release the screws (57) holding the hydraulic motor (84) to the bearing cover (77) and remove the motor.
 13. Undo the screws (61) and remove the bearing cover (77) from the bearing bracket (75).
 14. Press the shaft assembly out of the bearing bracket from the pump end.
 15. The pump end bearing cover (76) can be removed from the bearing bracket (75) by releasing the bolts (55).
 16. Press the roller bearing (89) outer race out of the bearing bracket.
 17. Flatten the tags on the locking washers (92), prevent the shaft from rotating, and unscrew the bearing locknuts (91).
 18. Pull the angular contact ball bearings (2 off 90) off the shaft and remove the bearing spacer (78).
 19. Pull the roller bearing (89) inner race off the shaft.
- Dismantling is now complete. Inspect all parts for damage or wear.




Figure 12 Typical HS150HH pump




Figure 11 Typical HS150-SV pump

7.3.2 Reassembly

New seals and O-rings must be fitted when reassembling. It is also prudent to fit a new impeller retaining nut.

1. Heat the roller bearing (89) inner race and both angular contact ball bearings (2 off 90) with a temperature controlled bearing heater until they are a consistent 110°C. Do not overheat or allow the bearings to remain at this temperature for longer than their fitting time.



CAUTION. Bearing races must be pressed into position and not hammered either directly or by drift. Direct hammering will damage the bearing or rollers. Drift hammering will introduce swarf into the assembly. Either will result in early bearing failure.

2. Once up to temperature, slide the roller bearing (89) inner race up hard against the shaft shoulder, fit the bearing spacer (78) and slide the angular contact ball bearings (2 off 90) up hard onto the other shaft shoulder. Hold them in position for a minimum of 30 seconds. The lock nuts (91) fitted without the tab washers are suitable for this purpose. This allows the races to grip the shaft and prevent them from creeping away from the shoulder during cooling. Let the assembly cool completely.
3. Once cool, remove the lock nuts (91), fit the locking washers (92) and refit the lock nuts. Knock up at least two tags on the locking washers to secure.
4. Press the roller bearing (89) outer race sufficiently into the bearing bracket (75) bore so that it is deep enough to allow the bearing covers (76) spigot to engage with the bore. Fit the bearing cover without a lip seal (95) or O-ring (36) and press the outer race fully home.
5. Press the shaft assembly into the bearing bracket from the motor end until it is clamped hard together.
6. Remove the pump end bearing cover (76), fit a lip seal (95) and O-ring (36) and refit the cover.
7. Fit O-ring (36) to motor end bearing cover (77). Attach the cover to bearing bracket with screws (61).
8. Fit the hydraulic motor (84) and O-ring (37) to the bearing cover (77) and secure with screws (57) and spring washers (64). Note that the hydraulic motor front oil seal is NOT removed for this pump model.
9. Attach the adaptor (8) to the bearing bracket assembly using screws (57) and spring washers (64).
10. Attach lifting frame (11) to bearing bracket assembly using bolts (54), spring washers (63) and nuts (69).
11. Clean the shaft thoroughly and lubricate with clean water or a diluted soft soap solution. **Do not use** heavy grease, silicone or PTFE based lubricants, as these would prevent the seal from gripping the shaft.



CAUTION. *Mechanical Seals are precision engineered devices. Extreme care must be taken to ensure that no damage occurs to the lapped faces. These faces must be kept absolutely clean throughout the entire installation. Do not touch them or allow any contaminant to come into contact with them. Soiled faces will have to be cleaned with appropriate degreasing cleaner and soft tissue. Failure to observe these precautions will lead to premature seal failure.*

12. Press the seal seat into the adaptor (8).
13. Carefully slide the rotating parts of the first mechanical seal (29) over the shaft until they abut the seal seat. Set the seal to the dimension given in the technical Data section and lock lightly in position tightening the grub screws evenly a part turn at a time.
14. Slide the rotating parts of the second mechanical seal (29) over the shaft until they abut the first seal. Lock lightly in position tightening the grub screws evenly a part turn at a time. Confirm that both seals are correctly positioned and tighten the grub screws fully.
15. Place an O-ring (34) in the groove in the inner wear plate (4), place the seal seat (27) and seal clamp plate (7) in position and secure with screws (59) and spring washers (66).
16. Fit an O-ring (38) to the inner wear plate (4) and fasten to the adaptor assembly using socket head cap screws (60).
17. Attach the rear wear plate (6) to the adaptor (8) using studs (53), rubber bonded washers (40) and nuts (10).
18. Fit the key (4) and impeller (3) to the shaft. Secure with the impeller retaining nut (47) and washer (48).
19. Measure the clearance between rear of impeller and rear wear plate. Remove the impeller and add shims (15, 16, 17 & 18) at 'X' as necessary to obtain the clearance given in the Technical Data section.
20. Refit the impeller, lock the assembly with a bar through the vanes of the impeller and torque the retaining screw to the value given in the Technical Data section.
21. Fit the front wear plate (5) to the front cover (2) using screws (57) and bonded rubber washers (40).
22. Attach the front cover and wear plate to the pump body (1) using studs (51), spring washers (64) and nuts (70).
23. Fit the pump body assembly to the bearing bracket, wear plate and impeller assembly with studs (52), spring washers (64) and nuts (70). Measure the clearance between the front of the impeller and front wear plate. Remove the pump body from the assembly and fit gaskets (21, 22, 23 & 24) at 'Y' to obtain the clearance given in the Technical Data section. Reassemble and recheck.
24. Attach the strainer (9) to the front cover with screws (57) and bonded rubber washers (40).
25. Fill the seal chamber with oil (see Technical Data section) ensuring that no air pockets remain and plug off with plug (45).
26. Fill the bearing chamber with oil (see Technical Data section) ensuring that no air pockets remain and plug off with plugs (2 off 45).

Assembly is now complete, but before attaching the hydraulic lines, the unit must be partially filled with hydraulic oil to prevent dry running on start up.

7.4 HS300 pumps

Note that dismantling and reassembly procedures refer to the item numbers in the illustration and are correct for a directly corresponding build.




Figure 13 HS300 cross section

7.4.1 Dismantling

The HS300 arrangement differs from the rest of the range because of the extra weight and bulk of the unit. It has an external lifting bracket. This does not require removal for maintenance tasks such as wear plate, impeller or mechanical seal replacement.

1. Disconnect and remove all hydraulic and discharge piping and the hydraulic motor from the pump.
2. Remove the two plugs (51) from the bearing and seal chambers and drain the oil.

3. Using suitable lifting gear rotate the whole unit 90° until it is resting with the shaft horizontally and the pump mounting foot towards the ground.
4. Remove the 4 off nuts, bolts and washers (81, 74 & 62) holding the strainer to the frame.
5. Support the strainer (10) and remove the 8 off nuts, bolts and washers (81, 74 & 62) holding it to the strainer support (9). Slide the strainer out sideways from the frame.
6. Steady the strainer support (9) and remove the 4 off nuts, & washers (81 & 74) holding it to the front cover (2). Ease the strainer support forwards until access can be gained to the nuts holding the front cover to the pump body (1). Let it rest on the front cover.
7. Remove the 4 off nuts and washers (81 & 74) holding the front cover to the pump body. After removal attach suitable lifting gear to the front cover and loose strainer support. Fit 4 off M12 x 45 (minimum length) screws to the holes in the front cover and jack it (complete with front wear plate and loose strainer support) clear of the pump body (1). Remove this assembly sideways from the frame.
8. Remove the loose strainer support from around the front cover. The front wear plate (5) and the front of the impeller (3) may now be inspected for wear or damage. If necessary, the front wear plate can be detached from the front cover by removing the retaining nuts and washers (72 & 80).
9. Inspect the hydraulic motor end of the shaft. If there are two flats on the top diameter, then an anti-rotation tool is available to aid in further dismantling. If there are no flats then a suitable block of wood must be wedged between an impeller blade and the pump body discharge to prevent rotation. Fit the anti-rotation tool or wedge the impeller.
10. Remove the cover (item 19 - 80mm A/F) in the centre of the impeller (3) to expose the retaining screw (64).
11. Knock down the tab on the tab washer (18) and slacken the retaining screw (64) to remove the tension. Do not undo by more than one or two turns. The impeller will be removed later in the procedure. If the impeller was wedged in position, remove the wedge.

NOTE: - If only the mechanical seal requires replacement carry out instructions 15 to 22 at this point and then reassemble.

12. Return the frame and remainder of the pump to the upright position. Support the bolted in cross member whilst removing its fastening bolts, nuts and washers (105, 107, 108 & 109). Remove the cross member.
13. Remove the 8 off nuts and washers (81 & 74) attaching the bearing bracket and adaptor assembly to the pump body (1).
14. Attach suitable lifting gear to the bearing bracket and adaptor assembly and using the screws (59), jack the assembly (including the impeller) clear of the pump body. Remove this assembly to a suitable place for further dismantling.
15. With the removed assembly horizontal, completely undo the impeller retaining screw (64) and remove the tab washer (18) and impeller washer (16).
16. Pull the impeller (3) off the splines on the shaft (23). Note the number and size of shims on the shaft behind the impeller for reference when re-assembling. NOTE:- The face against which the impeller is fitted is part of the mechanical seal assembly and care must be taken not to damage it any way during further dismantling. The exposed rear wear plate (6) can now be inspected for wear or damage.
17. If fitted remove the anti-rotation tool.
18. To remove the rear wear plate (6), remove the 6 off nuts and washers (80 & 72) securing it to the adaptor. Using the 2 off screws (61) the rear wear plate can be jacked off the adaptor.
19. 4 off socket cap screws (56) are now exposed. Undo them to remove the inboard seal seat carrier (item 4 wear plate). Take care in removal not to damage either the seal seat attached to the back of the carrier or the seal sleeve on the shaft.
20. Remove the 4 off screws and spring washers (57 & 71) holding the seal clamp ring (7). Push out the inboard seal seat (12).
21. The double mechanical seal (13) is a one piece assembly and it can now be withdrawn from the shaft.
22. The outboard seal seat carrier (11) can now be released from the adaptor (8) by undoing and removing the 4 off socket cap screws and washers (55 & 70). The outboard seal seat (14) can now be pushed out of the carrier (11).
23. Separate the adaptor (8) from the bearing bracket (20) assembly by undoing and removing the 8 off nuts, bolts and washers (63, 74 & 81).
24. Undo the screws and spring washers (60 & 73) and remove the bearing cover (22) from the bearing bracket (20).
25. Press the shaft assembly out of the bearing bracket from the pump end.
26. The pump end bearing cover (21) can be removed from the bearing bracket (20) by releasing the 6 off screws and spring washers (58 & 72).
27. Remove the spacer (28) from the bearing bracket.
28. Press the roller bearing outer race (part of 24) out of the bearing bracket.
29. Flatten the locking washers (26) tags, prevent the shaft from rotating, and unscrew the bearing locknuts (27).
30. Pull the 2 off angular contact ball bearings (25) off the shaft.
31. Pull the roller bearing inner race (part of 24) off the shaft.
32. The pump body (1) may now be removed from the lifting frame (100).

Dismantling is now complete. Inspect all parts for damage or wear.

7.4.2 Reassembly

New seals, O-rings and impeller retaining screw must be fitted when reassembling.

1. Heat the roller bearing inner race (part of 24) and both angular contact ball bearings (2 off 25) with a temperature controlled bearing heater until they are a consistent 110°C. Do not overheat or allow the bearings to remain at this temperature for longer than their fitting time.



CAUTION. *Bearing races must be pressed into position and not hammered either directly or by drift. Direct hammering will damage the bearing or rollers. Drift hammering will introduce swarf into the assembly. Either will result in early bearing failure.*

2. Once up to temperature, slide the roller bearing inner race up hard against the shaft shoulder, fit the bearing spacer (28) and slide the angular contact ball bearings up hard onto the other shaft shoulder. Hold them in position for a minimum of 30 seconds. The lock nuts (27) fitted without the tab washers are suitable for this purpose. This allows the races to grip the shaft and prevent them from creeping away from the shoulder during cooling. Let the assembly cool completely.
3. Once cool, remove the lock nuts (27), fit the locking washers (26) and refit the lock nuts. Knock up at least two tags on the locking washers to secure.
4. Press the roller bearing outer race (part of 24) into the bearing bracket (20) leaving it about 1mm proud of the end. Fit the bearing cover (21) with 6 off screws and spring washers (58 & 72). Tighten evenly until the cover is flat and square against the bearing outer race. Continue tightening half a turn at a time and press the outer race fully home.
5. Press the shaft assembly into the bearing bracket from the motor end until it is clamped hard together.
6. Fit O-ring (44) to motor end bearing cover (22). Attach cover to the bearing bracket with cap head screws and spring washers (60 & 73).
7. Fit filler elbow (85) and plug (52) to bearing cover (22) ensuring fill will be vertical when pump is fully assembled.
8. Take adaptor (8) and fit filler elbow, extension pipe, socket and plug (85, 86, 87 & 52). Ensure fill will be vertical when pump is fully assembled. Fit 2 off drain plugs (51).
9. Press the outboard seal seat (14) into the carrier (11). Fit the O-ring (40) to the carrier and secure into the adaptor (8) using 4 off socket cap screws and washers (55 & 70).
10. Fit the O-ring (37) to the top face of the adaptor (8). Orientate the adaptor correctly in relation to the bearing bracket assembly so that the oil filler assembly will pass through the hole in the bearing bracket and secure them together with 8 off bolts, nuts and spring washers (63, 74 & 81).
11. Press the inboard seal seat (12) into the carrier (4) and secure with the seal clamp ring (7) held by 4 off screws and spring washers (57 & 71).
12. Fit the one piece double mechanical seal (13) over the shaft ensuring that the seal faces meet and the seal sleeve is butted against the shaft shoulder.
13. Place the O-ring (38) over the inboard seal carrier (4) spigot. Pass the carrier over the shaft taking care not to damage the seal seat and locate it in the recess in the adaptor. Secure with 4 off cap headed screws (56).

NOTE: - The seal working lengths are obtained automatically and no setting is required.

14. Fit 6 off studs (66) to the rear wear plate (6). Position the rear wear plate and secure with 6 off nuts and spring washers (80 & 72).
15. Press the roll pin (15) into the end of shaft (23).
16. Slide the impeller (3) onto the shaft. Temporarily fit the impeller washer (16) without an O-ring and secure with a hand tight bolt. NOTE: - This bolt should not be the one used finally.
17. Measure the gap between the back of the impeller and the rear wear plate with feeler gauges at three positions 120° apart. Rotate the impeller 60° and measure again. Average the readings. If it is already less than the tolerances given in the Technical Data section, remove the impeller, add appropriate shims and refit.
18. If the hydraulic motor end of the shaft has two flats on the sides, an anti-rotation tool (available from Xylem Dewatering Solutions) can be fitted for the following process. If the shaft is plane ended, then a baulk of timber wedged across the impeller blades and against some suitably rigid structure will have to be employed.
19. Tighten the impeller bolt and recheck the clearance. If outside the given tolerance, remove the impeller and add or remove shims (30, 31, 32) as appropriate.
20. Once the correct running clearance has been achieved, remove the fastening bolt and discard. Remove the impeller washer and fit the O-ring (42) and roll pin (17). Replace the impeller washer, fit the tab washer (18) over the roll pin and secure all in place with the bolt (64) torqued to the value in the Technical Data section.
21. Fit the O-ring (43) to the impeller washer and screw down the impeller washer cover (item 19 – 80 A/F) fully.
22. Remove the anti-rotation tool or wedge.
23. Place the pump body (1), suitably supported from its front cover mounting face so that it's axis vertical. Fit 8 off studs (81) to the adaptor face. Attach suitable lifting gear to the bearing bracket/adaptor assembly. Lift the assembly, position it over the pump body, and orientate it so that the oil fillers are over the discharge trumpet and at right angles to the flange. Lower it into position on the pump body. Secure with 8 off nuts and spring washers (81 & 74).
24. Rotate the assembly to the horizontal.
25. Fit 4 off studs (65) to the front wear plate (5). Attach the front wear plate to the front cover (20) using 4 off nuts and spring washers (72 & 80).

26. Fit 4 off studs (67) every other hole in the pump body. Fit 4 off studs (68) in the remaining holes. Pass the front cover assembly over the studs and secure with 4 off nut and spring washers (74 & 81) on the shorter studs.
27. Measure the clearance between all impeller vanes and the front wear plate. Take the average and compare with the running clearance given in the Technical Data section. If required add or remove shims (33, 34, 35, 36) as appropriate.
28. Pass the strainer support (9) over the front cover and studs, locating it so that the larger holes in the support fit over the previously fitted nuts. Secure in place with 4 off nuts and spring washers (74 & 81).
29. Attach the strainer (10) to the strainer support with 8 off nuts, bolts, and washers (81, 74 & 62).
30. Rotate the whole assembly so that the shaft is vertical (strainer down) Tilt the lifting bracket (100) to angle of about 20° with the open side up and lift the pump assembly into place, allowing the frame to return to the vertical as it is done. Position within the bracket so that all securing bolts can be fitted. Secure with the appropriate nuts, bolts and washers.

NOTE: - Tolerances between the pump assembly and the lifting bracket can be several millimetres. It is recommended that the pump foot is fitted directly to the bracket and space elsewhere is made up with washers.

Assembly is now complete, but before attaching the hydraulic lines, the unit must be filled with oil in both the bearing bracket and seal chambers.

7.5 HS100NC & HS150NC Pumps

The HS100NC and HS150NC pumps share many parts with the 10022 and 15022 pumps, differing only in the volute, impeller and associated items. Therefore the method of dismantling and reassembly follow almost exactly the same procedures (see section 7.2) except for the following:-

7.5.1 Dismantling

After removing the strainer, the impeller must be loosened slightly before extracting the bearing bracket assembly (including the impeller) from the pump body.

Loosening the impeller will require the following tool in addition to a standard Allen key required to remove the impeller locking screw:
½" drive Hexagon head (Allen bit) 12mm x 65mm long (Figure 15

).

Remove access plug from pump body (shown in Figure 14) and insert an anti-rotation bar to prevent the impeller rotating.

Remove the impeller retaining cap screw (Figure 16) and washer (see Figure 17). The impeller will still be retained by the friction fit of the sleeve between the shaft and the impeller. Even if it this is dislodged the impeller will be retained within the body.




Figure 14 Typical HS100NC pump




Figure 15 1/2" drive Hexagon head (Allen bit) 12mm x 65mm




Figure 16 Removal of impeller retaining cap screw




Figure 17 Typical HS100NC & HS150NC cross sectional view

To break the friction fit between the impeller sleeve and the shaft, the adjustment screw is turned **anticlockwise** (it is left hand threaded -Figure 18) using the 65mm long Allen key (Figure 15). Turn sufficiently until it contacts the shaft and **just** breaks the engagement.

Refit the impeller washer and screw hand tight as a security measure. This will ensure that the impeller is retained on the shaft when the bearing bracket assembly is removed from the volute.




Figure 18 Detaching impeller from shaft

The impeller is then removed from the shaft by undoing and removing the hand tight impeller screw and washer. The impeller, impeller sleeve and adjustment screw can then be removed.




Figure 19 Removal of impeller and sleeve

All remaining dismantling procedure follow those in section 7.2.1.

7.5.2 Reassembly

7.5.2.1 GUIDE PIN FITTING

The HS100NC and HS150NC are fitted with a 'chopper' insert ring. It is critical to efficient operation of the pump that the guide pin used is fitted correctly.

Place impeller on flat surface – blades up.

Locate insert ring on the impeller, ensure the insert ring is centralized on the impeller (Figure 20).

Insert Ring

Impeller



Figure 20 Locating insert ring on impeller

The guide pin comprises of three items, lip (1), cap screw (2) and nut (3) (Figure 21).



Figure 21 Lip, cap screw and nut

Assemble the cap screw into the lip and apply non setting thread lock compound to the cap screw (Figure 22).



Figure 22 Applying non-setting thread lock compound

Place nut on to the cap screw and fit the assembly in to the locating slot (Figure 23).



Figure 23 Locating guide pin assembly into insert ring

Align the guide pin lip with the centre boss of the impeller (Figure 24).



Figure 24 *Aligning the guide pin lip with the centre boss of the impeller*

Hold the lip tip firmly against the centre of the impeller boss and tighten the cap screw with Allen wrench until it is held in place (Figure 25).



Figure 25 *Tightening the cap screw with Allen wrench*

Place the complete assembly into a vice and then tighten the cap screw using a torque wrench (Figure 26) to the correct torque. Check cap screw size and see Technical data section for detail.



Figure 26 *Tightening the cap screw with torque wrench*

7.5.2.2 IMPELLER FITTING

The impeller is fitted to the tapered shaft by means of a tapered sleeve with an adjusting screw locked onto the shaft with a screw and washer (Figure 27).

1. Impeller
2. Impeller sleeve and adjustment screw
3. Impeller screw
4. Washer




Figure 27 Impeller & fittings

Inspect the end of the shaft for any damage, remove any burrs and polish off any flaws with fine emery cloth.

Lightly apply grease film to the shaft end and remove any surplus grease from the taper.

Lightly apply a grease film to the inside of the tapered sleeve and remove any surplus grease.

Lightly grease the threads of the adjustment screw if needed, remove any surplus grease.

NOTE! The impeller can become loose. Remove any surplus grease from the conical and cylindrical surfaces of the shafts and sleeves.

Important: Before any assembly begins rotate the adjustment screw until it is level with the sleeve (Figure 28). This is the initial setting up point for the impeller.

The adjustment screw has a left hand thread. Turning it clockwise moves it outward and turning it anti-clockwise moves it into the sleeve.

The adjustment screw is used to adjust the clearance between the impeller and the insert ring (wear plate).




Figure 28 Taper sleeve and adjustment screw

Insert the taper sleeve (2) complete with adjustment screw (3) in its correct position into the impeller (1) (Figure 29).

Lightly lubricate the impeller cap head screw.

Load impeller complete as above on the shaft.

Insert the impeller cap head screw with its plain washer and **hand** tighten, this will ensure the impeller is in the correct position on the taper, and prevent the impeller falling off during further assembly.

Continue with assembly, attaching the bearing bracket/impeller assembly to the volute.




Figure 29 Impeller, sleeve and adjustment screw

7.5.2.3 ADJUSTING IMPELLER FRONT CLEARANCE

Unscrew and remove the impeller cap screw and flat washer.

Using the Hexagon head (Allen bit) 12mm x 65mm long with extension bars (Figure 30 if needed) turn the adjustment screw clockwise by hand until the impeller firmly makes contact with the wear plate (insert ring).




Figure 30 Hexagon head (Allen bit) and extension bar

Remove the Hexagon head (Allen bit), reach into the pump inlet and check the impeller cannot be rotated from this position by hand.

Insert the anti-rotation bar through the access plug in the pump body to prevent the impeller rotating.

Fit the lubricated impeller cap screw and flat washer.

Tighten the impeller cap screw to the correct torque using a torque wrench, and then turn it an extra 1/8 turn (45°) with a wrench or bar. (Check cap screw size and see Section 10.4 Table 2 for values).

Using feeler gauges reach into the pump inlet and measure the available impeller to wear plate (insert ring) clearance.

The minimum acceptable running clearance is 0.2mm (0.008")

Important: Remove the anti-rotation bar and replace access plug in the pump body.




Figure 31 Cross-section of pump inlet

8 WARRANTY

Unless special arrangements have been agreed and signed by both parties Xylem Dewatering Solutions will apply the following policy over defects found after delivery.

We will make good, by repair or the supply of a replacement, defects which, under proper use, appear in the goods within a period of twelve calendar months after the goods have been delivered ⁽¹⁾ and arise solely from faulty design (other than a design made, furnished or specified by you for which we have disclaimed responsibility in writing), materials or workmanship: provided always that defective parts have been returned to us if we shall have so required. We shall refund the cost of carriage on such returned parts and the repaired or new parts will be delivered by us free of charge.

Our liability under this clause shall be in lieu of any warranty or condition implied by law as to the quality or fitness for any particular purpose of the goods, and save as provided in this clause we shall not be under any liability, whether in contract, tort or otherwise, in respect of defects in goods delivered or for any injury ⁽²⁾, damage or loss resulting from such defects as from any work done in connection therewith.

- (1) For export orders, within a period of twelve calendar months after the goods have been delivered or, if delivery is delayed by reason of customer instructions or lack of instructions, within a period of 18 months after the goods have been notified as ready for despatch (whichever period expires the earlier)
- (2) For UK orders, other than personal injury caused by our negligence as defined in Section 1 of the Unfair Contract Terms Act, 1977.

9 FAULT FINDING

If possible fit a suction and pressure gauge to assist fault finding and check pump rating

POSSIBLE CAUSE	FAULT						REMEDY
	Pump dose not discharge sufficient head	Repeated mechanical seal failure	High oil temperature	Milky hydraulic oil	Aerated hydraulic oil		
Pump end blocked or worn	√		√				Clean/repair pump
Discharge hose kinked or blocked	√	√					Clear obstruction
Worn hydraulic motor or pump	√	√					Replace
Pump end running slow	√						Check prime mover speed. Check hydraulic oil flow from control end under load
Blocked return filter element		√					Renew
Return hose too long		√					Check with table for maximum hose lengths
Hose coupling failing to operate properly (if quick release couplings are employed)		√	√				Clean, repair or replace
Insufficient oil			√		√		Fill reservoir or increase in size
Pressure or return line blocked			√				Clean, repair or replace
Water contamination causing emulsification				√			Drain all system oil Check reservoir for water entry Pump mechanical seal failure – replace

10 TECHNICAL DATA

10.1 HS80, HS100, HS100-SG, HS103, HS150, HS150V & HS150V-SG Pumps

PUMP		HS80	HS100	HS100-SG	HS103	HS150	HS150V HS150V-SG
Rotation		ACW looking at impeller from suction end	See Note 1	ACW looking at impeller from suction end			
Max pump speed	rpm	2600	2400	2400	2200	1500	2400
Max head	m (ft)	25 (82)	35 (115)		52	20 (66)	33 (108)
Max flow	m ³ /hr (Imp. gpm)	80 (293)	200 (733)	175	230	400 (1466)	432 (1590)
Nominal solids capacity	Ø mm (")	40 (1.575)	45 (1.77)		75	65 (2.56)	127 (5)
Impeller clearance (front and rear)	mm (")	0.50 – 0.63 (0.020 – 0.025)			0.4 – 0.5 (0.015 – 0.020)		Rear 0.50 – 0.63 (0.020 – 0.025) Front N/A
Impeller screw (nut) torque	Nm (lbs.ft)	98 (72)	197 (145)				
Mechanical seal setting dimension	mm (ins)	N/A		N/A		N/A	
Mechanical seal oil		N/A. Seal is fed from hydraulic system	Any SAE 20/20 or Biopus 46 Biodegradeable				
Bearing bracket oil		N/A		SAE 20/20			
Discharge connection		Female 3"NPT or 3"BSP	Female 4"NPT or 4"BSP	Flanged 4" ASA150 or 4" BS10 Table D	Female 4"NPT or 4"BSP	Female 6"NPT or 6"BSP	150V: -Female 6"NPT 150V-SG: -Flanged 6" ASA150
Bearing bracket leakage connection size		¼"BSPT female	¾" NPSM for ASA150 or NPT units; ¾" BSPT female for BS10 or BSP units				
Hydraulic motor interface							
Flange		SAE 'A' 2 bolt			SAE 'B' 2 bolt	SAE 'C' 4 bolt	
Shaft		1 1/8" x 24 straight sided serrations to BS2059: 1953	SAE 'A' spline Ø15.5 9 teeth 16/32 DP		SAE spline Ø21 13 teeth 16/32 DP	SAE spline 1 ¼" 14 teeth 12/24 DP	
Xylem Dewatering Solutions supplied motors							
Drive pressure	bar (psi)	280 (4060)	250 (3625)				
Flow & Return connection size (supplied with quick release couplings on 8022, 10022 & 10022)		½"BSPT female	¾"BSPT female				
Bearing leakage connection size (supplied with quick release couplings on 8022, 1002 & 15022)		¼"BSPT female	¾"BSPT female				
Pump leakage connection size		N/A			N/A		
Hydraulic oil		Fluid conforming to ISO 32-46 <i>Standard</i> Shell Tellus Oil 27 <i>Biodegradeable</i> Shell Naturelle Fluid HF-E 32 Shell Naturelle Fluid HF-E 46 Texaco Rando HD 32 or 46 Texaco Rando HDZ 32 or 46 Texaco Hydra 46 Terrasolve Envirollogic 132					
Max flow	l/min @ rpm	12.0 @ 2600	36 @ 2300	55.9 @ 1670		100@2000	

NOTES. 1.Exercise particular caution with these units. Early 10022 are CW looking at impeller from suction end; later units are ACW.

10.2 HS150HH, HS200, HS200-SG, HS250 & HS300 Pumps

PUMP		HS150HH	HS200	HS200-SG	HS250	HS300
Rotation		ACW looking at impeller from suction end				
Max pump speed	rpm	2000				1800
Max head	m (ft)	100 (328)	40 (131)			63
Max flow	m ³ /hr (Imp. gpm)	275 (1000)	750 (2750)	700	760 (2785)	1368
Nominal solids capacity	Ø mm (")	35 (1.375)	75 (2.95)	79	75	95
Impeller clearance (front and rear)	mm (")	0.50 – 0.63 (0.020 – 0.025)			0.50 – 0.63 (0.020 – 0.025)	
Impeller screw (nut) torque	Nm (lbs.ft)	633 (467)				240
Mechanical seal setting dimension	mm (ins)	34 ± 0.3 (1.339 ± 0.012)				N/A
Mechanical seal oil		SAE 20/20 or Bioplus 46 Biodegradeable				
Bearing bracket oil		SAE 20/20				
Discharge connection		Flanged 6"ASA 150	Flanged 8" ASA150	Flanged 8" BS10 Table D	Flanged 10" BS10 Table D	Flanged 12" ASA150
Hydraulic motor interface						
Flange		SAE 'D' 4 bolt	SAE 'C' 4 bolt			SAE 'D' 4 bolt
Shaft		SAE spline 1 ¾" 13 teeth 8/16DP	14 teeth	SAE spline 1 ¼" 12/24 DP		SAE spline 1 ¾" 13 teeth 8/16DP
				17 teeth		
Xylem Dewatering Solutions supplied motors						
Drive pressure	bar (psi)	N/A	250 (3625)			310 (4495)
Flow & Return connection size (supplied with quick release couplings on HS80, HS100 & HS150)		1 1/4"BSPT female				Twin 1 1/2"BSPT female
Bearing leakage connection size (supplied with quick release couplings on HS80, HS100 & HS150)		½" BSPT female				¾" BSPT female
Pump leakage connection size			7/8"-14 UNF			
Hydraulic oil		Fluid conforming to ISO 32-46 <i>Standard</i> Shell Tellus Oil 27 Texaco Rando HD 32 or 46 Texaco Rando HDZ 32 or 46 <i>Biodegradeable</i> Shell Naturelle Fluid HF-E 32 Shell Naturelle Fluid HF-E 46 Texaco Hydra 46 Terrasolve Envirologic 132				
Max flow	l/min @ rpm	N/A	100 @ 2000			320@1800

10.3 HS100NC & HS150NC Pumps

PUMP		HS100NC	HS150NC
Rotation		ACW looking at impeller from suction end	
Max pump speed	rpm	2200	
Max head	m (ft)	40 (131)	52 (170)
Max flow	m ³ /hr (Imp. gpm)	225 (825)	370 (1356)
Nominal solids capacity	Ø mm (")	35 (1.37)	42 (1.65)
Impeller clearance (front and rear)	mm (")	0.2mm to 0.8mm (0.008" to 0.031")	
Impeller screw (nut) torque	Nm (lbs.ft)	76 (56)	
Mechanical seal oil		N/A. Seal is fed from hydraulic system	
Bearing bracket oil		N/A	
Discharge connection		4" NPT or 4" BSP	6" NPT or 6" BSP
Bearing bracket leakage connection size		3/4" NPT for NPT units or 3/8"BSPP for BSP units	
Hydraulic motor interface			
Flange		SAE 'B' 2 bolt	SAE 'C' 4 bolt
Shaft		SAE 'B' spline 13 teeth 16/32 DP	SAE 'C' spline 14 teeth 12/24 DP
Xylem Dewatering Solutions supplied motors			
Drive pressure	bar (psi)	250 (3625)	
Flow & Return connection size		3/4"BSPT female	1"BSPT female
Bearing leakage connection size		3/8"BSPT female	1/2"BSPT female
Pump leakage connection size		N/A	
Hydraulic oil		Fluid conforming to ISO 32-46 <i>Standard</i> Shell Tellus Oil 27 Texaco Rando HD 32 or 46 Texaco Rando HDZ 32 or 46 <i>Biodegradeable</i> Shell Naturelle Fluid HF-E 32 Shell Naturelle Fluid HF-E 46 Texaco Hydra 46 Terrasolve Envirollogic 132	
Max flow	l/min @ rpm	60 @ 2000	100 @ 2000

10.4 Fastener Torques

The following tables give the recommended tightening torques for general purpose metric and UNC fasteners. They are to be used only when the joint is metal to metal (i.e. no joints or gaskets) and no special figures (e.g. for impeller retaining bolts) have been quoted.

Table 2 Metric Fasteners

Thread Size	Steel		Stainless
	Torque (N-m)		
	Nuts & Bolts	Nuts on Studs	All
M6 x 1.0	11.7	4.6	9
M8 x 1.25	28	11	22
M10 x 1.5	56	22	44
M12 x 1.75	98	38	76
M16 x 2.0	244	95	187
M20 x 2.5	476	185	364
M24 x 3.0	822	320	629
M30 x 3.5	1633	633	1240

Table 3 UNC Fasteners

Thread Size	Steel		Stainless
	Torque (N-m)		
	Nuts & Bolts	Nuts on Studs	All
¼" - 20	13.5	5.4	10.5
5/16" - 18	27.1	10.5	21.0
3/8" - 16	48.8	20	37.8
7/16" - 14	74.6	30	57.8
½" - 13	122	48	94.6
5/8" - 11	237.3	95	183.9
¾" - 10	420.4	167	325.8
7/8" - 9	664.4	266	514.9
1" - 8	1003	401	777.3

Table 1 figures are for Metric fasteners to BS3692. Steel fasteners: - Grade 8.8 for bolts, Grade 4.6 for studs, Grade 10 for nuts; Stainless Steel fasteners: - Grade A2 or A4, Class 70 or 80.

Table 2 figures are for UNC fasteners to BS1768 Steel fasteners: -Grade S and Grade 3 for nuts; Stainless Steel fasteners: - Grade A2.

If steel fasteners are of dissimilar condition then the figures Table 1 or Table 2 must be multiplied by those in Table 3.

Table 4 Correction factors

		PLATING CONDITION OF BOLT	
		BLACK	ZINC
PLATING CONDITION OF NUT	BLACK	1.0	0.9
	ZINC	0.9	0.8

NOTES