

Instructions for using Cottage Kit



1. Install suction pipe and foot valve on Jet pump
2. Install Street Tee supplied by threading male threads into the Discharge of the Jet pump
3. Place funnel in vertical opening and fill pump and suction line with water, it will take more water than expected
4. Remove funnel and plug vertical opening with pipe plug
5. Attach discharge pipe to horizontal female NPT opening and finish installing piping
6. Start pump
7. Pump and line should be fully primed, check prime by opening a faucet
8. If water is delivered in full stream pump is fully primed, if intermittent flow is experienced start from step 3 to fully prime the system.



Part Number for Cottage Kit : **CTGKIT**
Included in kit: Street Tee and Funnel

Xylem Inc.

2881 East Bayard Street Ext., Suite A, Seneca Falls, NY 13148

Phone: (866) 325-4210 Fax: (888) 322-5877

www.xylem.com/goulds